



Weatherproof Cabinet

Instructions for Installation

Thank you for purchasing this weatherproof cabinet. Your purchase will provide your air compressor many years of protection from the elements. Following are a few simple guidelines to assist you with installing the cabinet.

1. It is recommended that the cabinet be set up off the ground a couple inches. Patio blocks or treated lumber works well. Since the cabinet is molded from UV stabilized polypropylene, it will not rust or corrode even if left in contact with the ground, however, slightly elevated is suggested.
2. Do not locate the cabinet in an area where flooding is possible. The cabinet is not waterproof from the bottom and flooding will likely result in damage to compressor inside cabinet.
3. The cabinet comes with a pre-drilled hole and grommet for the incoming power supply line.
A power outlet can be mounted inside the cabinet or the compressor can be hard wired. Please contact a qualified electrician for electrical installation.




ALWAYS install ground fault protection (GFI) when using electric near water!

4. Two 1 1/4" diameter holes are pre-drilled in floor of cabinet for outgoing air line(s). A plug is included to seal second hole if only one airline is used. If both holes are needed for airlines, disregard plug.

Optional Fan:


In hot climates or when using larger air compressors (which create more heat) an optional fan is recommended. If you bought your cabinet with the fan at time of purchase it will come installed in the cabinet and is ready to go. You simply need to plug it in. If hard wiring your air compressor, it is suggested you cut plug off fan cord and hard wire it as well.



A variety of air compressors can be used inside this cabinet. Actual installation may vary based on compressor and number of airlines used.

Retro-fitting Cabinet with Fan:

If retro-fitting a cabinet with fan, center the fan on the opening. Mark hole placement and drill holes for mounting. Use proper size bolts to secure fan to cabinet. Line up the bolts and secure the fan and fan guard to the cabinet. Use of lock nuts or lock washers is recommended.



EasyPro Pond Products Limited Warranty

EasyPro Pond Products ("EasyPro") warrants to the purchaser that this product ("Product") will be free from any mechanical or material defects for a period of:

Cabinet: **five years** from the date of purchase.

Fan (if installed SC25F1, SC25F2): **one year** from the date of purchase.

This warranty only covers properly installed and maintained Products sold by authorized EasyPro Sellers who are subject to and follow EasyPro's quality control standards. Please note that because EasyPro is unable to control the quality of Products sold by unauthorized sellers, unless otherwise prohibited by law, this warranty does not cover Products purchased from unauthorized sellers.

This warranty does not cover normal wear and tear, nor any deterioration suffered through overloading, improper use, negligence, improper installation, acts of God or accident. Similarly, any modification made by the purchaser to the Product will cause the warranty to be null and void. This warranty does not cover any cost associated with the installation or removal of the Product subject to a warranty claim.

All returned items will be inspected to determine cause of failure before a warranty claim is approved.

The exclusive remedies provided hereunder shall, upon EasyPro's inspection and option, be either repair or replacement of the Product or parts covered under this warranty.

Making a Claim: A Return Authorization ("RA") number must first be obtained by calling EasyPro at 800-448-3873 or via email at warranty@easypro.com. It is the purchaser's responsibility to pay the return shipping charges. Be sure to include the RA number, original receipt (in the form of an invoice or sales receipt), your name, your return address and your phone number inside of the package. No warranty claims will be honored without the original receipt that shows that your purchase was made from an Authorized EasyPro Seller. Ensure the product is properly packaged and insured for the replacement value. Damage due to improper packaging is the responsibility of the sender.

ALL OTHER EXPRESS OR IMPLIED WARRANTIES INCLUDING MERCHANTABILITY OF FITNESS FOR A PARTICULAR PURPOSE ARE HEREBY LIMITED IN DURATION TO THE DURATION OF THE WARRANTY AS DESCRIBED ABOVE. Some States do not allow limitations on how long an implied warranty lasts, so the above limitations may not apply to you.

EasyPro shall not be held liable for any damages caused by defective components or materials of this Product; or for loss incurred because of the interruption of service; or any consequential/incidental damages and expenses arising from the production, sale, use or misuse of this Product. Some States do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you.

EasyPro shall not be held liable for any loss of fish, plants or any other livestock as a result of any failure or defect of this Product. This warranty gives you specific legal rights, and you may also have other rights that vary from State to State.



Grant, MI 49327 800-448-3873 www.EasyPro.com